



Lenovo Yoga-900-13ISK2 Battery Replacement

This guide will show you how to remove the battery in your Lenovo Yoga-900-13ISK2.

Written By: Nathan Lui



INTRODUCTION

This guide will show you how to remove the battery in your Lenovo Yoga-900-13ISK2.

TOOLS:

- [T6 Torx Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Back Panel





- Flip the laptop so that the back panel is facing up.
- Remove the ten 4.0mm T6 Torx screws from the back of the laptop.

Step 2





- Gently lift the back cover off of the laptop.

Step 3 — Battery




- Push the black battery cable towards the battery to disconnect it.

Step 4



- Remove the six #0 3.8mm Phillips screws from the battery.

Step 5



- Gently lift the battery out of the laptop chassis.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 10:57:37 AM.